Experiment - 5

Aim: Install a print server in LAN

Step 1: Network Setup

- 1. Opened Cisco Packet Tracer and added the following devices:
- o 1 x Server (acting as the print server)
- o 1 x Printer
- o 1 x Switch
- o 2 x PCs
- 2. Connected all devices using Copper Straight-Through cables.

Step 2: Configure IP Addresses

- 1. Server (Print Server) Configuration
- Click on Server0 > Config > FastEthernet0.
- o Set:

```
IP Address: 192.168.1.1
Subnet Mask: 255.255.255.0
```

- o Save the settings.
- 2. Printer Configuration
- Click on Printer > Config > FastEthernet0.
- o Set:

```
IP Address: 192.168.1.10
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.1.1
```

- o Save the settings.
- 3. PC1 and PC2 Configuration
- Click on PC1 > Desktop > IP Configuration.
- o Set:

```
IP Address: 192.168.1.100
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.1.1
```

o Repeat the same process for PC2, setting its IP to 192.168.1.101.

Step 3: Enable FTP Service on the Server

- 1. Click on Server0 > Services tab.
- 2. Select FTP from the services list.
- 3. Click ON to enable the FTP server.
- 4. Create a new FTP user:

```
Username: printer
```

Password: 1234

5. Save the settings.

Step 4: Create a File on PC1

- 1. Click on PC1 > Desktop > Text Editor.
- 2. Type a sample text (e.g., "Test print job").
- 3. Click Save As and name the file test_print.txt.
- 4. Ensure the file is saved.

Step 5: Upload the File to the Print Server via FTP

- 1. Click on PC1 > Desktop > Command Prompt.
- 2. Connect to the FTP server:

```
ftp 192.168.1.1
```

3. Enter the FTP credentials:

Username: printer Password: 1234

4. Upload the file:

```
put test_print.txt
```

5. If successful, the file will be transferred to the server.

Step 6: Verify the Uploaded File

- 1. Click on Server0.
- 2. Go to Services > FTP.
- 3. Check if test print.txt appears in the uploaded files list.